ASSEMBLY STEPS: STORAGE BOOT SNAP TOGETHER TO INSTALL ON KABOAT, CUT TUBE SHORTER... ...AND DRILL HOLE IN NEW POSITION ADJUSTABLE STRAPS **CARRY BAG** SLIDE TOP TUBES INTO SLEEVES OF BIMINI TOP FABRIC ASSEMBLED TOP TUBES POLE V-TUBES INTO STRAIT TUBES SNAP ALL 4 STRAIT TUBES TO TOP TUBES INSIDE SLEEVES BIMINI WITH ALL TUBES ASSEMBLED TOGETHER SLIDE STRAP WITH LOOP END THROUGH CUT OUT IN BIMINI TOP FABRIC, AND THEN SLIDE OTHER END OF STAP THROUGH THAT LOOP, AND PULL. USE ROPE TO PUSH TOGETHER BIMINI END POLES TO REACH DISTANCE LESS THAN 56"